

RETOUCHING JOINERY

Retouching is like servicing joinery.

While washing it, check if the coating film has suffered any accidental damage. Coating film scratches or breaks can easily be repaired by simply retouching, to avoid further damage to the wooden structure caused by the infiltration of water.



Procedure

To be performed only on the part that requires a repair. Identify the damaged parts and clean the surface with **HH 8011**. Then use a brush to apply Sayerlack waterborne transparent coating Linea Blu **HF 204X** or pigmented coating **HL 206X** in the desired colour.

Once dry, make sure that the damage has been effectively repaired and, if necessary, apply a second coat.

If the surface damage cannot be repaired with minor work, we recommend that you follow the instructions for re-coating.



How often

Depending on the degree of conservation of the coating film.



Materials to be used

Animal/synthetic combination bristle brush, waterborne transparent topcoat Linea Blu **HF 204X** or waterborne pigmented topcoat Linea Blu **HL 206X** in the desired colour.

